

## Legends Car Quick Adjustment Guide



		Tight			Loose		
		Entrance	Center	Exit	Entrance	Center	Exit
RF	Tire Pressure	Lower	Lower	Lower	Raise	Raise	Raise
	Spring	Soften	Soften	Soften	Stiffen	Stiffen	Stiffen
	Camber	More Neg		More Neg	Less Neg		Less Neg
LF	Tire Pressure	Raise	Raise	Raise	Lower	Lower	Lower
	Spring	Stiffen		Stiffen	Soften		Soften
	Camber	More Pos		More Pos	Less Pos		Less Pos
Front	Both Springs	Soften	Soften	Soften	Stiffen	Stiffen	Stiffen
Cross Weight		Decrease	Decrease	Decrease	Increase	Increase	Increase
Brakes	Bias	More Rear			More Front		
	Rear Drums	Tighten			Loosen		
RR	Tire Pressure	Raise	Raise	Raise	Lower	Lower	Lower
	Spring	Stiffen	Stiffen	Stiffen	Soften	Soften	Soften
	Trailing Arm		Lengthen			Shorten	
LR	Tire Pressure	Lower	Lower	Lower	Raise	Raise	Raise
	Spring	Soften		Soften	Stiffen		Stiffen
Rear	Both Springs	Stiffen	Stiffen	Stiffen	Soften	Soften	Soften
	Pinion Angle						Increase

Check out more quick adjustment guides at [www.rjracingproducts.com](http://www.rjracingproducts.com)!